
Eureka!

INSTRUCTIONS | Mountain Pass 2 (2629102)



TENT CONTENTS

9

Tent body + Tent fly Tent footprint Complete pole assembly Stakes (11) Guylines (6) Gear loft

QUESTIONS?

Johnson Outdoors Gear, Inc. USA: 1-800-572-8822 www.eurekacamping.com Johnson Outdoors Canada Canada: 1-800-263-6390 www.eurekatentscanada.com

TENT TIPS

fly + tent body at 4 corners. Adjust fly tension via corner webbing. Stake out vestibules. Attach guylines to guyout loops. Stake out all guylines (additional

stakes required).

- · Always stake down tent, including all guyout points.
- · Increase interior airflow by opening the fly vent, various windows, and using the High/Low Air Exchange fly feature.

TENT CARE

- · Make sure the tent is completely dry, then store loosely rolled in a dry
- · Clean your tent by setting it up and wiping it down with a mild soap and luke warm water. Never use laundry detergent, washing machines or dryers.

WARRANTY

· Your Eureka! tent is covered by a limited lifetime warranty. For more details please visit the website or contact customer service.